


# Necklace MP3 Player User Manual (NM-618)

## 1. Layout of the remote control



- ① ■/>I: Play / Pause
- ② +/ >>I: Previous / Volume up  
*Press it to play previous track*  
*Press and hold it to turn the volume up*
- ③ -/ I<<: Next / Volume down  
*Press it to skip to next track*  
*Press and hold it to turn the volume down*
- ④ Earphone / USB port
- ⑤ LED indicator  
*The indicator will be off when battery runs low*  
*The indicator will blink during charging process*  
*The indicator will light after completing charging*

## 2. Playing music

The MP3 Player has employed EasyPlay® technology to simplify the operation. It turns on and starts to play automatically when connecting the earphones to the remote control; it turns off automatically when disconnecting the earphones.

## 3. Downloading music

Connect the MP3 Player to computer for downloading music via the provided USB cable.

## 4. Charging

Please charge the player by connecting it to computer via the provided USB cable or by USB Power Adapter (please purchase it separately).